

# ILAFPJ08 REMOTE CONTROLL CODES TABLE (ver1.2)

UPDATED 2009/07/29

1. Maker code

73 H

2. Operatrion code

Code	Button	Normal Remote Controlle	Repeat	CONTENTS
00H	-			
01H	↑	○	○	UP
02H	↓	○	○	DOWN
03H	BACK	○	×	Back/Undisplays message,adjustment gauge,menu
04H	-			
05H	ON	○	×	Powers on
06H	STAND BY	○	×	Stand By
07H	-			
08H	INPUT	○	×	Switches "INPUT" in the following order (HD350/RS10) HDMI1→HDMI2→COMP→Video→S-Video→HDMI1 Switches "INPUT" in the following order (HD750/RS20) HDMI1→HDMI2→COMP→Video→S-Video→PC→HDMI1
09H	BRIGHT	○	×	Displays adjustment gauge of Brightness
0AH	CONT	○	×	Displays adjustment gauge of Contrast
0BH	RNR(+)	-	○	Displays adjustment gauge of RNR/+ in adjustment gauge
0CH	RNR(-)	-	○	Displays adjustment gauge of RNR/- in adjustment gauge
0DH	MNR(+)	-	○	Displays adjustment gauge of MNR/+ in adjustment gauge
0EH	MNR(-)	-	○	Displays adjustment gauge of MNR/- in adjustment gauge
0FH	BNR(On)	-	×	Switches to BNR (On)
10H	BNR(Off)	-	×	Switches to BNR (Off)
11H	Detail Enhance(+)	-	○	Displays adjustment gauge of Detail Enhance/+ in adjustment gauge
12H	Detail Enhance(-)	-	○	Displays adjustment gauge of Detail Enhance/- in adjustment gauge
13H	Quick Align	-	×	Automatically adjust angle of analog PC signal
14H	SHARP	○	×	Displays adjustment gauge of Sharpness
15H	COLOR	○	×	Displays adjustment gauge of Color deepness
16H	TINT	○	×	Displays adjustment gauge of Tint
17H	-			
18H	N.R	○	×	Displays Noise reduction adjustment bar
19H	-			
1AH	-			
1BH	Keystone_V(+)	-	○	Keystone Correction V(+)
1CH	Keystone_V(-)	-	○	Keystone Correction V(-)
1DH	HIDE	○	×	Switches Hide ON/OFF
1EH	-			
1FH	-			
20H	LENS.AP	○	×	Switches setting of iris (HD350/RS10) Displays adjustment bar of Iris setting (HD750/RS20)
21H	Shift(U)	-	○	Shift the lens up
22H	Shift(D)	-	○	Shift the lens down
23H	V-stretch(On)	-	×	Switches V-stretch on
24H	V-stretch(Off)	-	×	Switches V-stretch off
25H	Aspect(4:3)	-	×	Switches Aspect to 4:3
26H	Aspect(16:9)	-	×	Switches Aspect to 16:9
27H	Aspect(Zoom)	-	×	Switches Aspect to Zoom
28H	Lens.AP(1)	-	×	Switches Lens.AP to 1
29H	Lens.AP(2)	-	×	Switches Lens.AP to 2
2AH	Lens.AP(3)	-	×	Switches Lens.AP to 3
2BH	-			
2CH	Shutter(ON)	-	×	Closes lens barrier
2DH	Shutter(OFF)	-	×	Opens lens barrier
2EH	Menu	○	×	Displays/undisplays menu
2FH	OK	○	×	OK
30H	Lens	○	×	Displays adjustment menu of Lens control/Switches setting of lens(focus/zoom/shift)
31H	Focus(+)	-	○	Focus far
32H	Focus(-)	-	○	Focus near
33H	-			
34H	→	○	○	Moves the cursor to right/+ in adjustment gauge
35H	Zoom(T)	-	○	Zoom tele
36H	←	○	○	Moves the cursor to left/- in adjustment gauge
37H	Zoom(W)	-	○	Zoom wide
38H	Gamma Normal	-	×	Switches Gamma to Normal
39H	Gamma A	-	×	Switches Gamma to A
3AH	Gamma B	-	×	Switches Gamma to B
3BH	Gamma C	-	×	Switches Gamma to C
3CH	Gamma Custom1	-	×	Switches Gamma to Custom1
3DH	Gamma Custom2	-	×	Switches Gamma to Custom2
3EH	Gamma Custom3	-	×	Switches Gamma to Custom3
3FH	-			
40H	Keystone_H(+)	-	○	Keystone Correction H(+)
41H	Keystone_H(-)	-	○	Keystone Correction H(-)
42H	-			
43H	Shift(R)	-	○	Shift the lens to right
44H	Shift(L)	-	○	Shift the lens to left

45H	-			
46H	PC		x	Switches to PC terminal (HD750/RS20)
47H	-			
48H	-			
49H	-			
4AH	-			
4BH	VIDEO	-	x	Switches to VIDEO terminal
4CH	S-VIDEO	-	x	Switches to S-VIDEO terminal
4DH	COMP.	-	x	Switches to COMP terminal
4EH	C.Temp 5800K	-	x	Switches C.TEMP to 5800K
4FH	C.Temp 6500K	-	x	Switches C.TEMP to 6500K
50H	C.Temp 7500K	-	x	Switches C.TEMP to 7500K
51H	C.Temp 9300K	-	x	Switches C.TEMP to 9300K
52H	C.Temp High Bright	-	x	Switches C.TEMP to High Bright
53H	C.Temp Custom1	-	x	Switches C.TEMP to Custom1
54H	C.Temp Custom2	-	x	Switches C.TEMP to Custom2
55H	C.Temp Custom3	-	x	Switches C.TEMP to Custom3
56H	CEC(On)	-	x	Switches CEC on
57H	CEC(Off)	-	x	Switches CEC off
58H	-			
59H	TEST	O	x	Displays TEST pattern
5AH	-			
5BH	-			
5CH	CTI (Off)	-	x	Switches to CTI (Off)
5DH	CTI (Low)	-	x	Switches to CTI (Low)
5EH	CTI (Middle)	-	x	Switches to CTI (Middle)
5FH	CTI (High)	-	x	Switches to CTI (High)
60H	ColorMana(Off)	-	x	Switches ColorManagmant off (HD750/RS20)
61H	ColorMana(Cu1)	-	x	Switches ColorManagmant to "Custom1" (HD750/RS20)
62H	ColorMana(Cu2)	-	x	Switches ColorManagmant to "Custom2" (HD750/RS20)
63H	ColorMana(Cu3)	-	x	Switches ColorManagmant to "Custom3" (HD750/RS20)
64H	-			
65H	-			
66H	-			
67H	STAGE	O	x	Switches to "STAGE" in Picture Mode
68H	CINEMA2	O	x	Switches to "CINEMA2" in Picture Mode
69H	CINEMA1	O	x	Switches to "CINEMA1" in Picture Mode
6AH	NATURAL	O	x	Switches to "NATURAL" in Picture Mode
6BH	DYNAMIC	O	x	Switches to "DYNAMIC" in Picture Mode
6CH	USER1	O	x	Switches to "USER1" in Picture Mode
6DH	USER2	O	x	Switches to "USER2" in Picture Mode
6EH	USER3	O	x	Switches to "USER3" in Picture Mode
6FH	THX	O	x	Switches to "THX" in Picture Mode (HD750/RS20)
70H	HDMI 1	-	x	Switches to HDMI 1
71H	HDMI 2	-	x	Switches to HDMI 2
72H	-			
73H	-			
74H	INFO	O	x	Displays information page of menu
75H	GAMMA	O	x	Switches "GAMMA" in the following order Normal/A/B/C/Custom1/ Custom2/ Custom3
76H	C.TEMP	O	x	Switches "C.TEMP" in the following order 5800K/6500K/7500K/9300K/HB/Custom1/Custom2/Custom3
77H	ASPECT	O	x	Switches "ASPECT" in the following order VIDEO MODE: 4:3/16:9/Zoom PC MODE: Auto/1:1/Full
78H	Contrast(+)	-	O	Displays adjustment gauge of Contrast/+ in adjustment gauge
79H	Contrast(-)	-	O	Displays adjustment gauge of Contrast/- in adjustment gauge
7AH	Bright(+)	-	O	Displays adjustment gauge of Brightness/+ in adjustment gauge
7BH	Bright(-)	-	O	Displays adjustment gauge of Brightness/- in adjustment gauge
7CH	Color(+)	-	O	Displays adjustment gauge of Color deepness/+ in adjustment gauge
7DH	Color(-)	-	O	Displays adjustment gauge of Color deepness/- in adjustment gauge
7EH	Sharpness(+)	-	O	Displays adjustment gauge of Sharpness/+ in adjustment gauge
7FH	Sharpness(-)	-	O	Displays adjustment gauge of Sharpness/- in adjustment gauge